


Dear Duilio,

This document specifies both the connection diagram and the assembly scheme of the system according to the photo that you sent me of the valves, considering the averages.

The proof of concept is made for a valve as requested, but I was thinking that a mobile or desktop application could be made to communicate with the ESP-32 since it is a card that works as IoT, I put that suggestion to your criterion.


Do not hesitate to contact me if you have any questions or difficulties, I will be willing to help

ELEMENTS




SPECIFICATION

- Input Current: 0~5A
- Output Current: 0.5-4.0A
- Control Signal: 3.3~24V
- Power (MAX): 160W
- Micro Step: 1, 2/A, 2/B, 4, 8, 16, 32
- Temperature: -10~45°C
- Humidity: No Condensation
- Dimension: 96*56*33 mm/ 3.78*2.2*1.3 inches
- Weight: 0.2 kg
- Drive IC: TB67S109AFTG




The driver must be connected from 9 to 42V and the ESP-32 Card must be connected with 3.3 V.





STEP MOTOR




Current (A)	Peak current	S4	S5	S6
0.5	0.7	ON	ON	ON
1.0	1.2	ON	OFF	ON
1.5	1.7	ON	ON	OFF
2.0	2.2	ON	OFF	OFF
2.5	2.7	OFF	ON	ON
2.8	2.9	OFF	OFF	ON
3.0	3.2	OFF	ON	OFF
3.5	4.0	OFF	OFF	OFF

S1	S2	S3	Microstep resolution
ON	ON	ON	NC
ON	ON	OFF	Full step
ON	OFF	ON	1/2 step
OFF	ON	ON	1/2 step
ON	OFF	OFF	1/4 step
OFF	ON	OFF	1/8 step
OFF	OFF	ON	1/16 step
OFF	OFF	OFF	1/32 step




TB 6600 Driver

- The configuration of the switches so that the driver can command the NEMA 17 stepper motor is shown in the images shown



STEP MOTORS

- Each motor cable is connected according to the color in the connection diagram



89

Send

Start...

Valve: 0

I received: 23

This is the position function

The valve is openning

The valve is opened

You change the position of the valveLevel saved in memory, this is the actual position:

23I received: 89

This is the position function

The valve is openning

The valve is opened

You change the position of the valveLevel saved in memory, this is the actual position:

89

☒ Autoscroll

Both NL & CR



115200 baud



Clear output

COM8

10|

Send

configsip: 0, SPIWP:0xee

clk_drv:0x00,q_drv:0x00,d_drv:0x00,cs0_drv:0x00,hd_drv:0x00,wp_drv:0x00

mode:DIO, clock div:1

load:0x3fff0018,len:4

load:0x3fff001c,len:1216

ho 0 tail 12 room 4

load:0x40078000,len:10864

load:0x40080400,len:6432

entry 0x400806b8

Start...

Valve: 89

I received: 10

This is the position function

The valve is closing

The valve is closed

You change the position of the valveLevel saved in memory, this is the actual position:

10

☒ Autoscroll

Both NL & CR

115200 baud

Clear output